


PROKERLAM SQUARE

ANODIZED AND POLISHED ALUMINIUM

profiles for low thicknesses



EXAMPLES AND INSTRUCTIONS FOR LAYING METHODS



PROKERLAM SQUARE is a square corner bead profile in anodized and polished aluminium suitable to protect the external corners of coverings with low thickness. It can be used like connection profile between step tread and riser of stairs coated with ceramic and mosaic with low thickness. Its particular section and the availability in three different finishes make **PROKERLAM SQUARE** a much sought-after profile that allows a workmanlike application even with low thickness coverings.

ANODISED SILVER ALUMINIUM thermo packed

bar length 2,7 lm - pack 40 Pcs - 108 lm

Article	H mm
PKLQAA 045	4,5

POLISHED CHROME/GOLD ALUMINIUM thermo packed

bar length 2,7 lm - pack 40 Pcs - 108 lm

Article	H mm
PKLQBC 045	4,5
PKLQBO 045	4,5

1. Choose "PROKERLAM SQUARE" according to the desired finish.
2. Cut "PROKERLAM SQUARE" to the desired length and apply the adhesive on the support where the profile will be laid.
3. Press the anchoring flange of "PROKERLAM SQUARE" into the adhesive.
4. Lay the tiles, aligning them with the profile leaving a 2 mm joint. Remove immediately all remains of adhesive from the surface of the profile.
5. Fill the joints between the profile and the tiles with grout, in order to avoid water stagnation. Remove immediately all the remains of grout from the surface of the profile.




COLOURS



PROKERLAM JOLLY

ANODIZED AND POLISHED ALUMINIUM

profiles for low thicknesses



EXAMPLES FOR LAYING



PROKERLAM JOLLY is a quarter-circle rounded bead profile in anodized and polished aluminium suitable to protect the external corners of coverings with low thickness. It can be used like connection profile between step tread and riser of stairs coated with ceramic and mosaic with low thickness. Its particular section and the availability in three different finishes make **PROKERLAM JOLLY** a much sought-after profile that allows a workmanlike application even with low thickness coverings.

ANODISED SILVER ALUMINIUM thermo packed

bar length 2,7 lm - pack 40 Pcs - 108 lm

Article	H mm
PKLJAA 045	4,5

POLISHED CHROME/GOLD ALUMINIUM thermo packed

bar length 2,7 lm - pack 40 Pcs - 108 lm

Article	H mm
PKLJBC 045	4,5
PKLJBO 045	4,5

COLOURS




INSTRUCTIONS FOR LAYING

1. Choose "PROKERLAM JOLLY" according to the desired finish.
2. Cut "PROKERLAM JOLLY" to the desired length and apply the adhesive on the support where the profile will be laid.
3. Press the anchoring flange of "PROKERLAM JOLLY" into the adhesive.
4. Lay the tiles, aligning them with the profile leaving a 2 mm joint. Remove immediately all remains of adhesive from the surface of the profile.
5. Fill the joints between the profile and the tiles with grout, in order to avoid water stagnation. Remove immediately all the remains of grout from the surface of the profile.

PROKERLAM LINE

ANODIZED AND POLISHED ALUMINIUM

profiles for low thicknesses



EXAMPLES FOR LAYING (for instructions see PROKERLAM SQUARE)



PROKERLAM LINE is a Y-shaped profile in anodized and polished aluminium suitable to protect the external corners of coverings in low thickness. It can be used like connection profile between step tread and riser of stairs coated with ceramic and mosaic with low thickness. Its particular section and the availability in three different heights and finishes and special pieces such as internal and external corners, end caps and joints make **PROKERLAM LINE** a much sought-after profile that allows a workmanlike application even with low thickness coverings.

ANODISED SILVER ALUMINIUM thermo packed

bar length 2,7 lm - pack 40 Pcs - 108 lm

Article	H mm
PKLLAA 045	4,5
PKLLAA 10	10
PKLLAA 125	12,5

POLISHED CHROME/GOLD ALUMINIUM thermo packed

bar length 2,7 lm - pack 40 Pcs - 108 lm

Article	H mm
PKLLBO 045	4,5
PKLLBC 045	4,5
PKLLBC 10	10
PKLLBC 125	12,5

COLOURS



1. Choose "PROKERLAM LINE" according to the desired finish.
2. Cut "PROKERLAM LINE" to the desired length and apply the adhesive on the support where the profile will be laid.
3. Press the anchoring flange of "PROKERLAM LINE" into the adhesive.
4. Lay the tiles, aligning them with the profile leaving a 2 mm joint. Remove immediately all remains of adhesive from the surface of the profile.
5. Fill the joints between the profile and the tiles with grout, in order to avoid water stagnation. Remove immediately all the remains of grout from the surface of the profile.

* = On demand, price and delivery time to be agreed.